

# TAKACAT

## BRIDLE / TOW KIT Fitting Instructions

1. Loop the Dyneema through the bottom D-Ring as shown.



2. Connect the D-Shackles to the Inboard D-Rings on the Bow of each tube.



3. The Ring can be fitted between the D-Rings Underneath the Deck for towing or Float between the D-Rings on the tube and the Floor D-Rings for Anchoring or a higher tow point.